

# Consul

## Quality and Economy.

Lightweight yet durably constructed, the CONSUL is designed specifically for audiovisual use. Specified for schools worldwide. The CONSUL's legs are of sturdy gabled steel. 60" and 70" sizes feature suspension slat saddle, keeping viewing surface flat. Case adjusts easily to any level on tripod upright.

### Viewing Surfaces

Available with fiberglass matt white or glass beaded viewing surfaces. 1½" black masking borders are optional.

### Features and Options

#### Case Color

Steel case and endcaps finished in black.

#### Keystone Eliminator (optional)

Will extend top of viewing surface forward up to 9".

#### Carrying Case (optional)

Black leatherette zippered carrying case available (see below).



Optional  
Carrying Case



## Consul Dimensions

Size (H x W)	Shipping Wt. (lbs.)	Dimensions Closed (H x W x L)
<i>1:1 AV Format</i>		
50" x 50"	16	5⅜" x 4½" x 53⅜"
60" x 60"*	22	5⅜" x 4½" x 63⅜"
70" x 70"*	24	5⅜" x 4½" x 73⅜"

\*Also available with Keystone Eliminator.

Draper, Inc. ♦ 765.987.7999 ♦ [www.draperinc.com](http://www.draperinc.com)

# Luma 2/R

## Heavy-Duty for Use with Floor Stand.

The LUMA 2/R is a heavy-duty screen designed to use in a FLOOR STAND. This screen is an attractive and practical choice wherever a large, portable spring-roller screen is required. Constructed entirely of heavy gauge components for years of dependable operation, even in the rental market.

### Viewing Surfaces

Standard viewing surface is fiberglass matt white (glass beaded available). NTSC format screens have black borders on all four sides. Black borders on AV format screens are available. 1½" wide on sizes through 70" x 70"; 2" wide on larger sizes.

### Features and Options

#### Case

The LUMA 2/R is housed in a black, scratch-resistant steel case. Black carpet covering on case is optional.

#### Floor Stand

Made of heavy gauge steel and anodized aluminum. Provides support for LUMA 2/R in an inverted position at floor level. The LUMA 2/R FLOOR STAND's telescoping upright holds top of viewing surface when extended (maximum of 12'). Shipping weight is 25 lbs.



## Luma 2/R Dimensions

Size (H x W)	Viewing Area (H x W)	Overall Size (H x W)	Shipping Wt. (lbs.)
<i>1:1 AV Format</i>			
72" x 96"	—	—	39
96" x 96"	—	—	41
7' x 9'	—	—	45
9' x 9'	—	—	48
8' x 10'	—	—	50
10' x 10'	—	—	56
9' x 12'	—	—	75
12' x 12'	—	—	85
<i>4:3 NTSC Video Format</i>			
10'	69" x 92"	73" x 96"	39
11'	78" x 104"	83" x 108"	45
150"	87" x 116"	92" x 120"	50
15'	105" x 140"	109" x 144"	75